

BATTERY REPLACEMENT

The battery should last the service life of the unit. Service life is dependent on a number of factors including but not limited to the number of recharge cycles, and proper care and maintenance of the battery by the end user. Contact manufacturer for any information you may need.

SAFE BATTERY DISPOSAL



Contains a maintenance-free, sealed, non-spillable, lead acid battery, which must be disposed of properly. Recycling is required. Failure to comply with local, state and federal regulations can result in fines, or imprisonment.

Please recycle.

⚠ WARNING – *To reduce the risk of serious injury or property damage:*

- *Do not dispose of the battery in fire as this may result in an explosion.*
- *Before disposing of the battery, protect exposed terminals with heavy-duty electrical tape to prevent shorting (shorting can result in injury or fire).*
- *Do not expose battery to fire or intense heat as it may explode.*

12 VOLT DC ADAPTER PLUG FUSE REPLACEMENT

The fuse in the plug end of the 12 Volt DC Adapter protects the adapter's charging circuit. If the built-in 120 Volt AC Charger operates, but the DC charging adapter does not, then this fuse may be opened (blown).

To replace the fuse:

1. Unscrew the end cap of the DC plug (counterclockwise).
2. Remove spring center contact and fuse.
3. Check fuse with a continuity checker.
4. If blown, locate a replacement 2 amp.
5. Replace the fuse, spring, contact and end cap.

6. Screw end cap clockwise until it is finger tight – DO NOT OVERTIGHTEN.

7. Test for proper operation of the 12 volt DC charging adapter.

Troubleshooting

Problem	Possible Solution
Unit will not charge	Make sure all of the unit's functions are turned off.
	Make sure a suitable gage extension cord is properly connected to both the unit and a functioning AC outlet.
	or Make sure the 12 volt DC charging adapter is properly connected to both the unit and a functioning DC power source.
	Check the connection to the AC or DC power source.
	Confirm there is a functioning AC or DC current.
Unit fails to jump-start	Check that the fuse in the 12 Volt DC Adapter is not blown.
	Make sure unit's Jump Starter Power Switch is in the on position.
	Make sure a proper polarity cable connection has been established.
	Make sure the unit is not being operated in the Compressor mode.

Problem	Possible Solution
Unit fails to jump-start (continued)	Check that the unit has a full charge. Recharge the unit if necessary.
Portable Compressor will not inflate	Make sure the Compressor Power Button has been pressed to turn the compressor on.
	Make sure the unit is not being operated in the Jump Starter mode.
	Make sure the SureFit® nozzle is securely screwed on to the valve stem when attempting to inflate tires; or that the nozzle adapter is securely screwed into the SureFit® nozzle and is inserted properly into the item to be inflated on all other inflatables.
	Check that the unit has a full charge. Recharge the unit if necessary.
USB Port will not power appliance	Make sure the USB Power Button is in the on position.
	Make sure all the USB Power/Fault Indicators light solid blue. If a fault condition exists in either of the USB Ports, the USB Power/Fault Indicators will flash blue. Refer to the Important Notes in the “USB Ports” section to remedy any faults.

Problem	Possible Solution
USB Port will not power appliance (continued)	Make sure that the total draw of all USB devices plugged into the USB Ports does not exceed 3.1A.
	Some USB-powered household electronics will not operate with this USB charging/power port. Check the manual of the corresponding electronic device to confirm that it can be used with this type of USB charging/power port.
	Check that the unit has a full charge. Recharge the unit if necessary.
LED Area Light does not come on	Make sure the Area Light Power Button is in the on position
	Check that the unit has a full charge. Recharge the unit if necessary.

Accessories

⚠ WARNING: Since accessories, other than those offered by DeWALT, have not been tested with this product, use of such accessories with this unit could be hazardous. To reduce the risk of injury, only DeWALT recommended accessories should be used with this product.

If you need assistance regarding accessories, please contact the manufacturer at 1-888-394-3392 or CustomerService@dewalt12volt.com.

Service Information

Whether you need technical advice, repair, or genuine factory replacement parts, contact the manufacturer at 1-888-394-3392 or CustomerService@dewalt12volt.com.

One Year Limited Warranty

The manufacturer warrants this product against defects in material and workmanship for a period of one (1) year from the date of retail purchase by the original end-user purchaser ("Warranty Period").

If there is a defect and a valid claim is received within the Warranty Period, the defective product can be repaired, replaced or refunded, without charge, in the following ways: (1) Return the product to the manufacturer for repair, replacement or refund at manufacturer's option. Proof of purchase may be required by manufacturer. (2) Return the product to the retailer where product was purchased for an exchange (provided that the store is a participating retailer). Returns to retailer should be made within the time period of the retailer's return policy for exchanges only (usually 30 to 90 days after the sale). Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges.

This warranty does not apply to: accessories, bulbs, fuses and batteries; defects resulting from normal wear and tear, accidents; damages sustained during shipping; alterations; unauthorized use or repair; neglect, misuse, abuse; and failure to follow instructions for care and maintenance for the product.

This warranty gives you, the original retail purchaser, specific legal rights and you may have other rights which vary in certain states or provinces. This product is not intended for commercial use.

90 DAY REFUND POLICY

If you are not completely satisfied with the performance of this product for any reason, you can return it within ninety (90) days from the date of purchase with a receipt for a full refund.

Please complete the Product Registration Card and return within 30 days from purchase of the product to: Baccus Global LLC, One City Centre, 1 North Federal Highway, Suite 200, Boca Raton, FL 33432. Baccus Global LLC, toll-free number: 1-888-394-3392. www.dewalt12volt.com

Specifications

Boost Ampere	1,400A peak battery, 700A instant
Battery Type	SLA, 12 volt DC, 21Ah
Input	120V AC, 60Hz, 13W or 12V DC, 0.6A
Compressor	120 PSI
USB Output	5V DC, 3.1A max.
12 Volt DC Adapter	12V DC

Imported by Baccus Global LLC, One City Centre,
1 North Federal Highway, Suite 200, Boca Raton, FL 33432
www.dewalt12volt.com 1-888-394-3392

Copyright © 2016 DeWALT. DeWALT® and the DeWALT Logo are trademarks of the DeWALT Industrial Tool Co., or an affiliate thereof and are used under license. The yellow/black color scheme is a trademark for DeWALT power tools & accessories.