## COMMON MISTAKES

- 1. Improper Z-Wave setup. Ensure that you fully program and test your Z-Wave network for proper operation prior to integration with g!
- Placing the Z-Wave RS-232 Adapter out of range of other Z-Wave devices. Z-Wave devices create a
  wireless, self-healing mesh network, and should be placed where they are in range to communicate
  with multiple other devices for best results.
- 3. Failure to set the CT30 to **Simple Mode** when integrating with a **g!** system.
- 4. Failure to install the Z-Wave USNAP Module.
- 5. Adding thermostats to the network after adding controllers. If thermostats are added after controllers the controllers must be updated.
- 6. Using a VRC0P-1LW that does not have the (+3) notation.
- 7. Failing to update the VRC0P-1LW firmware. Minimum Version: \$Leviton(C) 2008 V2.33S/Z-Wave 3.11.

Z-Wave Thermostat Comparison Chart							
	Feature						
Model	Auto Mode	Fan Modes	Remote Sensor	Decimal Temperature	Unsolicited Feedback	Green / Energy Save Mode*	Built-In Schedule
2GIG	No	On / Auto	No	Yes <sup>4</sup>	No	No <sup>6</sup>	Yes <sup>8</sup>
Honeywell	Yes <sup>1</sup>	On / Auto / Circulate	No	Yes <sup>5</sup>	Yes	No	Yes <sup>8</sup>
RCS	Yes	On / Auto / Circulate <sup>2</sup>	Yes³	No	Yes	Yes <sup>7</sup>	Yes <sup>9</sup>
Trane	Yes	On / Auto / Circulate <sup>2</sup>	No	No	Yes	Yes <sup>7</sup>	Yes <sup>8</sup>
Wayne Dalton	No	On / Auto	No	No	No	Yes <sup>7</sup>	No

- 1. Can be enabled.
- 2. Circulate must be enabled in thermostat programming.
- 3. Temperature only.
- 4. Feedback to .5° Celsius and Fahrenheit.
- 5. Feedback to .5° Celsius.
- 6. When Z-Wave is activated the "Save Energy" button on the thermostat is disabled.
- 7. Activated by button on thermostat.
- 8. Can be enabled. (Factory default is disabled.)